

Topic: How to install the 9364 bulb onto the Midmark light.

Step 1. Turn light head off and allow bulb (1) to cool for at least 5 minutes.

Step 2. Rotate the two release levers (2) up ¼ turn (located on each side of the light head) and remove plastic shield (3).

Step 3. Remove bulb by pulling bulb straight out of lamp socket (5) and discard.

Step 4. Using protective plastic the bulb is packaged in, align contact pins with socket holes and press bulb in firmly. When bulb is firmly seated there will be approximately a 1/8" gap between the base of bulb and bulb socket.

Step 5. Position plastic shield onto light head. Secure in place by rotating the two release levers down ¼ turn.

